



## Installation Instructions EZ-Go 6" ELECTRIC SPINDLE KIT 2001 and up

### FRONT INSTALLATION

- Jack up the front end of the cart and place it on the jack stands.
- Remove wheels and tires.
- Remove the tire rod ends from the spindles.
- Remove the spindles from the front axle. Clean and lubricate these bolts and king pin tube for the reinstallation of the spindles.
- Install spindles to the front axle using the stock king pin bolts and king pin tube.
- Reattach the tire rod ends to the new spindles.
- Securely tighten all bolts.
- Install wheels and tires.
- Take the cart off the jack stands and lower the cart.
- Drive the cart forward 10 – 20 feet and check the toe-in (Proper toe-in should be approximately 1/8").

### REAR INSTALLATION

- Jack up the rear end of the cart and lace jack stands on the frame in front of the springs.
- Remove the wheels and tires.
- Unbolt the bottom of the shocks.
- Unbolt the rear leaf springs from under the rear end and put them on top of the rear end.
- Install supplied axle seats in between axle & leaf springs.
- Place new shock mount plates on top of leaf springs and install new U-bolts.
- Replace OEM shackles with supplied longer shackles.
- Install supplied shock extensions to bottom of shocks and attach to new shock plates.
- Double check all nuts and bolts for tightness.
- Install wheels and tires.

## ELECTRIC REAR

