



Installation Instructions

CLUB CAR 10" A-ARM LIFT KIT

(1998 – UP ELECTRIC)

REAR

- Raise cart and support frame with jack stands.
- Remove rear bumper, bag well liner and two (2) body bolts in bag well.
- Remove spring shackles from frame.
- Remove brake cables.
- Remove u-Bolts from springs and remove leaf springs.
- Lower axle and install leaf spring relocation links. (Use link for drill template on rear frame cross member).
- Re-install leaf springs to spring location links.
- Install lift blocks between axle and leaf springs and install u-bolts.
- Tighten u-bolts and install shock extensions.
- Install new brake cables. (Cable extensions connect to pedal linkage).
- Re-install bag well bolts, liner & rear bumper

FRONT

- Remove tie-rods from steering arms.
- Remove OEM bumper, spindles, leaf spring, shocks and delta plates (upper A-arms).
- Install new A-arm carrier to existing spring mount plate and to front bumper mount.
- Install new upper A-arms using OEM support plates.
- Install new upper shock mount and reinstall shocks.
- Install new spindles to A-arms and install wheel hubs.
- Re-install tie-rods.
- Set wheel chamber using lower ball joints for adjustment.
- Adjust wheel toe, approximately 1/8" toe-in.