



Sport Step Installation

- Remove side bumper panels (Ez-Go)
- Use step for template
- Drill two 5/16" holes into frame
- Install step with aluminum spacer to cart
- Re-install bumper panels