



Installation Instructions

EZ-Go SPORT SHIFTER INSTRUCTIONS

- Remove original shift lever.
- Remove OE shifter mechanism from body.
- Align large hole in sport shifter base assembly with hole in cart body.
- Use sport shifter base assembly as drill template & drill 3 - 5/16" holes in cart body.
- Install sport shifter to cart body with supplied hardware.
- Reinstall OE shifter mechanism.
- Install new shift lever on OE shifter mechanism.
- Install 1/4" ball joint to new shift lever.
- With cart in neutral, adjust 1/4" ball joints until sport shifter lever is parallel to cart body.
- Install cover assembly to sport shifter base assembly & install shift knob.

