



Installation Instruction CC DS Clay Basket

Parts: Basket, left bracket, right bracket, (4) $\frac{1}{4}$ " x 2" Hex Head Cap Screw, (2) $\frac{1}{4}$ " x 1 $\frac{1}{2}$ " Hex Head Cap Screw, (6) $\frac{1}{4}$ " Lock Nuts, (10) $\frac{1}{4}$ " Flat Washers, (4) spacers.

1. Remove the (2) $\frac{1}{4}$ " Carriage Bolts from the Cowl Band (see Figure 1).
2. Remove the hex head bolt from (1) side of the windshield frame and install the appropriate bracket to that side (see Figure 1). Replace the carriage bolt with the 1 $\frac{1}{2}$ " hex head cap screw and nut. Install the opposite side in the same manner.
3. Attach the basket to the brackets using the (4) 2" hex head cap screws, (8) flat washers, (4) spacers, and (4) lock nuts.

