



Installation Instructions SPORT STEP



- Remove side bumper panels (EZ-Go).
- Use step for template.
- Drill two 5/16" holes into frame.
- Install step with aluminum spacer to cart.
- Re-install bumper panels.