

- Place nerf bar up to rocker panel at desired location.
- Mark holes to be drilled. **NOTE:** *Make sure hole locations do not interfere with any OE gussets or brackets on backside of rocker panels.*
- Drill two 5/16" holes through rocker panel.
- Install nerf bar brackets behind rocker panel with 1  $\frac{14}{4}$  x 1  $\frac{14}{4}$  spacer blocks and hardware provided.
- Repeat for other side of cart.

