



Installation Instructions


MARATHON GAS LIFT KIT

FRONT

- Jack up front end and place on jack stand, remove both front wheels.
- Remove the bumper, and the rod from the drag bar (the one that comes from the steering assembly). Save hardware for reinstallation.
- Remove the four (4) bolts on each side of the front end that hold the leaf springs to the front end.
- Remove the two (2) bolts and the rubber bushings from the bottom of the shock.
- Install the new FRONT LEAF SPRING RISERS to the frame leaving them loose until the front half installation is completed. Install the FRONT SHOCK EXTENDERS making sure the spring plates are bolted in place.
- Tighten everything up now and replace the bumper.

REAR

- Jack up the rear end of the cart from the body (frame) place jack stands on both sides, in front of the springs (you will need the jack to lower the axle) remove the tires.
- Remove the bottom shock bolts; lower the axle so you can re-move the springs.
- Place the two (2) COIL SPRING RISERS on the bottom, or the top of the axle spring mounts (the ones with the rubber pads on top)
- Now replace the springs, bolt on the REAR SHOCK EXTENSIONS (they will only fit one way).
- Put shocks back into place, and tighten everything up now.
- Now put on your new tires and wheels, then let cart down on the ground.



THIS KIT CONTAINS

- A** Coil Spring Risers – Rear (2)
- B** Front Leaf Spring Risers (2)
- C** Front Shock Extensions (2)
- D** Rear Shock Extensions (2)

Hardware, Instructions, & Safety Decal