





# **All Sports Manufacturing Inc. RXV 4" Drop Carrier Lift Kit**

**Visit [AllSportsLiftKits.com](http://AllSportsLiftKits.com) for more  
All Sports products!**




**1. Remove front cover. Then remove OEM control arms and spindles from cart. Save hardware for use in later steps.**




**2. Attach carrier to frame using four 3/8" x 1" bolts and four 3/8" nylocs. Tighten hardware.**






**3. Unbolt shock from stock location and re-attach with shock extension plates. Attach plate at top with OEM bolt and nyloc with spacer in-between. Attach mid-section with two 3/8" x 1" bolts and nylocs. Attach shock to plate with 3/8" x 2 1/2" bolt with nyloc. Tighten hardware. Repeat for opposite side.**



**4. Bolt control arms to bottom of the carrier using OEM bolts and nylocs. Tighten hardware.**






- 5. Attach new spindles to control arms using included 1/2" x 6" bolts, nylocs and SAE washers. Then attach tie rods to steering arms on spindles using OEM hardware. Tighten hardware and repeat for opposite side.**
- 6. Re-install OEM hubs on new spindles.**




- 7. Remove shock bottom from axle and install the shock extension brackets. Install bottom of bracket with a 10mm x 40mm bolt and the top of the bracket with a 3/8" x 2" bolt with 3/8" flat washer and 3/8" Nyloc. Tighten all hardware and repeat on opposite side.**





**9. Remove front of leaf springs from spring hangers. Install spring hanger extension plates at the front of the leaf springs. Use two plates per side and two 5/16" x 1" bolts and two 3/8" x 1" Bolts with nylocs. Re-attach leaf-spring using OEM bolt and nyloc. Repeat for opposite side and tighten all hardware.**



**10. Remove stock shackles and replace with new rear shackles using OEM hardware. Tighten all hardware.**